

## RCS2CR-SA6D


Cleanroom Robo Cylinder, Slider, Built-in Type, Actuator Width 58mm, 200V Servo Motor, Aluminum Base

Model Specification Items	<b>RCS2CR-SA6D</b>	<input type="checkbox"/>	<b>30</b>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Series	Type	Encoder type	Motor type	Lead	Stroke	Applicable controller	Cable length	Options
		I: Incremental A: Absolute	30:30W Servo motor	12: 12mm 6: 6mm 3: 3mm	50: 50mm 600: 600mm (50mm pitch increments)	T1: XSEL-J/K T2: SCON MSCON SSEL XSEL-P/Q XSEL-R/S	N: None P: 1m S: 3m M: 5m X□□: Custom length R□□: Robot cable	See options below.

\* See page Pre-47 for details on the model descriptions.



\*CE compliance is optional.



Technical References Appendix P.5

- POINT**  
Notes on selection
- When the stroke increases, the maximum will drop to prevent the ball screw from reaching the critical rotational speed. Use the actuator specification table below to check the maximum speed at the stroke you desire.
  - The load capacity is based on operation at an acceleration of 0.3G (0.2G for the 3mm-lead model). These values are the upper limits for the acceleration.
  - The cleanliness class 10 is for horizontal usage. Please note that the actuator may not support C10 when used on its side or in vertical orientation.
  - See page A-71 for details on push motion.

### Actuator Specifications

#### Lead and Payload

Model number	Motor output (W)	Lead (mm)	Max. Load Capacity		Rated thrust (N)	Stroke (mm)
			Horizontal (kg)	Vertical (kg)		
RCS2CR-SA6D-①-30-12-②-③-④-⑤	30	12	6	1.5	24.2	50~600 (every 50mm)
RCS2CR-SA6D-①-30-6-②-③-④-⑤		6	12	3	48.4	
RCS2CR-SA6D-①-30-3-②-③-④-⑤		3	18	6	96.8	

#### Stroke and Max. Speed/Suction Volume by Lead

Stroke Lead	50~450 (every 50mm)	500 mm	550 mm	600 mm	Suction Volume (NE/min)
12	800	760	640	540	50
6	400	380	320	270	30
3	200	190	160	135	15

Code explanation ① Encoder ② Stroke ③ Applicable Controller ④ Cable length ⑤ Options \*See page A-71 for details on push motion. (Unit: mm/s)

#### ① Encoder type/② Stroke

② Stroke (mm)	Standard price	
	① Encoder Type	
	Incremental	Absolute
	I	A
50	—	—
100	—	—
150	—	—
200	—	—
250	—	—
300	—	—
350	—	—
400	—	—
450	—	—
500	—	—
550	—	—
600	—	—

#### ④ Cable Length

Type	Cable symbol	Standard price
Standard	P (1m)	—
	S (3m)	—
	M (5m)	—
Special length	X06 (6m) ~ X10 (10m)	—
	X11 (11m) ~ X15 (15m)	—
	X16 (16m) ~ X20 (20m)	—
	R01 (1m) ~ R03 (3m)	—
Robot Cable	R04 (4m) ~ R05 (5m)	—
	R06 (6m) ~ R10 (10m)	—
	R11 (11m) ~ R15 (15m)	—
	R16 (16m) ~ R20 (20m)	—

\* See page A-59 for cables for maintenance.


#### ⑤ Options

Name	Option code	See page	Standard price
Brake (cable exiting from end)	BE	→ A-42	—
Brake (cable exiting from left)	BL	→ A-42	—
Brake (cable exiting from right)	BR	→ A-42	—
CE compliance	CE	→ A-42	—
Non-motor end specification	NM	→ A-52	—
Vacuum port on opposite side	VR	→ A-58	—

### Actuator Specifications

Item	Description
Drive System	Ball screw, ø10mm, rolled C10
Positioning repeatability	±0.02mm
Lost Motion	0.1mm or less
Base	Material: Aluminum, white alumite treated
Allowable static moment	Ma: 38.3 N·m, Mb: 54.7 N·m, Mc: 81.0 N·m
Allowable dynamic moment (*)	Ma: 8.9 N·m, Mb: 12.7 N·m, Mc: 18.6 N·m
Allowable overhang	220mm or less in Ma, Mb and Mc directions
Grease Type	Low dust generation grease (both ball screw and guide)
Cleanliness	Class 10 (0.1µm)
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)

(\*) Based on 5,000km of traveling life



## Dimensional Drawings

CAD drawings can be downloaded from the website.

[www.intelligentactuator.com](http://www.intelligentactuator.com)

For Special Orders








Appendix P.15



- (\*1) Connect the motor and encoder cables here. See page A-59 for details on cables.
- (\*2) After homing, the slider moves to the ME, therefore, please watch for any interference with surrounding objects.

\* Note that in order to change the home orientation, arrangements must be made to send in the product to IAI.



\* In the non-motor end model (NM), the new home position is set 3mm inward from the ME opposite of the motor-side.



ME: Mechanical end  
SE: Stroke end

### Dimensions of the Brake Section

R: Brake cable exiting from right



\* Adding a brake will increase the actuator's overall length by 26.5mm (39.8mm with the cable coming out the end), and its weight by 0.3kg.

### ■ Dimensions and Weight by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600
L	304.5	354.5	404.5	454.5	504.5	554.5	604.5	654.5	704.5	754.5	804.5	854.5
A	198	248	298	348	398	448	498	548	598	648	698	748
N	81	131	181	231	281	331	381	431	481	531	581	631
P	66	116	166	216	266	316	366	416	466	516	566	616
R	81	31	81	31	81	31	81	31	81	31	81	31
U	1	2	2	3	3	4	4	5	5	6	6	7
m	6	8	8	10	10	12	12	14	14	16	16	18
Weight (kg)	2.0	2.1	2.3	2.4	2.6	2.7	2.9	3.0	3.2	3.3	3.5	3.6

### ③ Applicable Controllers

RCS2CR-series actuators can be operated with the following controllers. Select an appropriate controller type according to your application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page		
Positioner mode		SCON-CA-30D①-NP-2-①	Up to 512 positioning points are supported.	512 points	Single-phase 100VAC Single-phase 200VAC 3-phase 200VAC (XSEL-P/Q/R/S ONLY)	126 VA max. *Power supply capacity will vary depending on the controller, so please refer to the instruction manual for details.	—	→ P643		
Solenoid valve mode			Actuators can be operated through the same control used for solenoid valves.	7 points						
Field network type			Movement by numerical specification is supported.	768 points						
Pulse-train input control type			Dedicated pulse-train input type	(—)						
Positioner multi-axis, network type		MSCON-C-1-30D①-V-0-①	Up to 6 axes can be operated. Movement by numerical specification is supported.	256 points	3-phase 200VAC (XSEL-P/Q/R/S ONLY)	126 VA max. *Power supply capacity will vary depending on the controller, so please refer to the instruction manual for details.	—	→ P655		
Program control type, 1 to 2 axes		SSEL-CS-1-30D①-NP-2-①	Program operation is supported. Up to 2 axes can be operated.	20,000 points					—	→ P685
Program control type, 1 to 8 axes		XSEL-①-1-30D①-N1-EEE-2-④	Program operation is supported. Up to 8 axes can be operated.	Varies depending on the number of axes connected						

\* This is for the single-axis MSCON, SSEL, and XSEL.

\* ① indicates the power-supply voltage type (1: 100V / 2: Single-phase 200V).

\* ④ indicates the power-supply voltage type (1: 100V / 2: Single-phase 200V / 3: Three-phase 200V).

\* ① indicates the encoder type (I: Incremental / A: Absolute).

\* ② indicates the XSEL type (J / K / P / Q / R / S).

\* ④ indicates field network specification symbol.