

ROBO Cylinder® **RCP4 Series**
Power CON PCON-CA



Newest additions to the series!



High Speed
High power
RCP4



Power CON Realizing

1.5 Times the Speed and Double the Payload

The Power CON 150 series boosts the performance of ROBO Cylinder
The **side-mounted motor specification** and **cleanroom specification**

- Improved dynamic performance (the speed is up to 1.5 times and payload is up to twice
*Specific values vary depending on the model.
- New functions designed to enhance maintainability enable preventative maintenance,
- The smart tuning function lets you set up the operation of your equipment optimally with



RCP4 Series Variations

Model type	Series	Shape	Type	External view	Actuator size (width)	Stroke	Ball screw lead (mm)	Maximum Speed (mm/s)	Maximum payload (kg)		Page
									Horizontal	Vertical	
Straight motor specification	RCP4	Slider type	SA5C		52mm	50~800	20	1440	6.5	1	P.9
			SA6C		58mm		12	900	9	2.5	P.11
			SA7C		73mm		6	450	18	6	P.13
		Rod type	RA5C		52mm		3	225	20	12	P.21
			RA5C		52mm	50~400	20	1440	10	1	P.21
			RA6C		61mm		12	900	15	2.5	P.23
			RA6C		61mm		6	450	25	6	P.23
			RA6C		61mm	50~500	3	225	25	12	P.23
			RA6C		61mm		24	1200	20	3	P.23
			RA6C		61mm		16	980	40	8	P.23
			RA6C		61mm		8	490	45	16	P.23
			RA6C		61mm		4	245	45	25	P.23
			RA6C		61mm		20	800	6	1.5	P.23
			RA6C		61mm		12	700	25	4	P.23
			RA6C		61mm		6	450	40	10	P.23
			RA6C		61mm		3	225	60	20	P.23

*The maximum horizontal payload for the rod type is for when an external guide is used in combination.

Controller


Series	Type	Page
PCON	CA	p.40

150% the Output, Achievable with Standard Controllers

standard motorized cylinders to amazing new heights.
(class 10) have been added to the power controller **RCP4** series.

IAI's conventional models*) significantly boosts the productivity of your system.

so less time is needed for maintenance.
ease.



RCP4-RA6C

RCP4-SA5R
RCP4-SA6R
RCP4-SA7R
RCP4-RA5R
RCP4-RA6R
RCP4CR-SA5C
RCP4CR-SA6C
RCP4CR-SA7C

Model type	Series	Shape	Type	External view	Actuator size (width)	Stroke	Ball screw lead (mm)	Maximum Speed (mm/s)	Maximum payload (kg)		Page
									Horizontal	Vertical	
NEW Side-mounted motor specification	RCP4	Slider type	SA5R		52mm	50~800	20	1440	6.5	1	P.15
			SA6R		58mm		12	900	9	2.5	P.17
			SA7R		73mm		6	450	18	6	P.19
			RA5R		52mm		3	225	20	12	P.25
		Rod type	RA6R		61mm	50~400	20	1280	10	1	P.27
			RA5R		52mm		12	900	15	2.5	P.29
			RA6R		61mm		6	450	25	6	P.31
			RA5R		52mm		3	225	25	12	P.33
			RA6R		61mm		24	1000	20	3	P.35
			RA5R		52mm		16	840	40	8	P.37
			RA6R		61mm		8	490	45	16	P.39
			RA5R		52mm		4	210	45	25	P.41
NEW Cleanroom specification	RCP4CR	Slider type	SA5C		52mm	50~800	20	800	6	1.5	P.29
			SA6C		58mm		12	700	25	4	P.31
			SA7C		73mm		6	450	40	10	P.33
			RA5C		52mm		3	225	60	20	P.35
			RA6C		61mm		24	800	20	3	P.37
			RA5C		52mm		16	560	50	8	P.39
			RA6C		61mm		8	420	60	18	P.41
			RA5C		52mm		4	175	80	28	P.43
			RA6C		61mm		20	1440	6.5	1	P.45
			RA5C		52mm		12	900	9	2.5	P.47
			RA6C		61mm		6	450	18	6	P.49
			RA5C		52mm		3	225	25	12	P.51

Features

Shorter Takt Time Significantly Boosts

New Functions of **RCP4** Actuator

1


1.5 times higher maximum speed and double the payload when combined with a Power CON 150

When the new controller (Power CON 150) equipped with our newly developed high-output driver (patent pending) is used, the maximum speed increases significantly by up to 1.5 times the levels achievable with IAI's conventional models, while the payload is greater by up to twice (*).

In addition to these amazing improvements in specifications, the maximum speed does not drop as much even when the payload increases due to increased torque with the high speed motor, meaning that dynamic performance equivalent to that of a higher-class model can be achieved at lower cost.

(*) The specific rates of improvement vary depending on the model.

Power CON 150 PCON-CA




Correlation Diagram of Speed and Payload

2

Extended lineup with the latest additions: the side-mounted motor specification and the cleanroom specification

Three slider types (SA5/SA6/SA7) and two rod types (RA5/RA6) are now available in the side-mounted motor specification characterized by a significantly shorter overall length for space-saving design. Three slider types are also available in the cleanroom specification conforming to cleanliness class 10.





3

the Productivity of Your System

3

The rod type <Radial Cylinder> with a built-in guide mechanism can carry radial loads over a long stroke (500mm).


The rod type <Radial Cylinder> has a built-in guide mechanism in the actuator to carry radial loads on the rod over a long stroke of up to 500 mm. The actuator can also support a radial load at a position offset from the center of the rod.



4

Easy replacement of the motor with removal of only one setscrew

The motor has been unitized for easy replacement. The actuator and motor unit can be separated and replaced by removing only one setscrew, so the time required for maintenance becomes significantly shorter.




* The same applies to the side-mounted motor type.

5

Slider types have mounting holes compatible with the RCP2

Slider types have mounting holes that are compatible with RCP2 actuators, meaning that you can replace your current RCP2 actuator with a RCP4 with ease. Also, the mounting holes provided on rod types are the same as those provided on slider types, instead of T-slots found on the RCP2, and reamed holes are also provided to significantly improve installation repeatability.



Features


New Functions to Enhance Maintainability

New Functions of Power CON 150 PCON-CA

6

Keep track of the production volume and utilization ratio with the total movement counter function

The total number of times the actuator has moved is counted and recorded in the controller, and a signal is output to an external device once the pre-defined count is exceeded. This function can be used to keep track of the production volume, utilization ratio, etc.



7

Know when to perform maintenance with the total travel counter function

The total distance travelled by the actuator is counted and recorded in the controller, and a signal is output to an external device once the pre-defined count is exceeded. By using this function, you know when to add grease or perform periodic maintenance.

8

Retain alarm generation times with the calendar function

The calendar function (clock function) lets you add timestamps to the history of alarms, etc. This information is useful in troubleshooting, etc.

Date type	Code	Message	Addr	Detail
detected last	FFF	PowerUP No Error	-----	11/11/16 11:19:38
History 1	OCE	Control power voltage reduction	-----	11/11/08 06:54:48
History 2	FFF	PowerUP No Error	-----	11/11/08 06:54:48
History 3	OCE	Control power voltage reduction	-----	11/11/08 03:41:37
History 4	OCE	Control power voltage reduction	-----	11/11/08 03:41:37
History 5	OCE	Control power voltage reduction	-----	11/11/08 03:41:37
History 6	OCE	Control power voltage reduction	-----	11/11/08 03:41:37
History 7	FFF	PowerUP No Error	-----	11/11/08 03:41:37
History 8			-----	11/11/08 03:41:37
History 9			-----	11/11/08 03:41:37
History 10			-----	11/11/08 03:41:37
History 11			-----	11/11/08 03:41:37
History 12			-----	11/11/08 03:41:37
History 13			-----	11/11/08 03:41:37
History 14			-----	11/11/08 03:41:37
History 15			-----	11/11/08 03:41:37

9

The smart tuning function lets you set up the operation conditions of your equipment optimally with ease

The smart tuning function is a new feature introduced to the ROBO Cylinder PC software (version 8.03.00.00 or later) and touch panel teaching pendant (model number: CON-PTA). When the actuator is connected to a controller supporting the smart tuning function, all the user needs is to enter the actuator type, transfer load, etc., and the optimal acceleration/deceleration and speed will be set automatically according to the load.

1. Setting the acceleration/deceleration from the speed

Enter a desired speed in the position data table, and the maximum settable acceleration/deceleration will be set automatically according to the pre-defined load-speed combinations.

2. Setting the acceleration/deceleration and speed from the travel

Specify the position data number associated with desired start/end positions of movement and set a desired travel distance, and the combination of acceleration/deceleration and speed that gives the shortest travel time will be set automatically.

10


Three controller operation types to choose from

1. Positioner type that operates the actuator via ON/OFF of PIOs

2. Pulse-train type that operates the actuator by sending pulses from the positioning unit


3. Field network type that operates the actuator by sending position data via the network

System Configuration




Model Specification Items


<Slider type>



<Rod type>



<Cleanroom type>



Actuator Options

Brake
Option code: B

All models

Description



A mechanism to hold the slider in place when the actuator is used vertically, so that it will not drop and damage the work part, etc., when the power or servo is turned off.

Optional cable exit direction
Option code: CJT
CJR
CJL
CJB
CJO

All models

Description

The actuator cable exit direction from the motor cover of the actuator is changed.





Motor side-mounted direction
Option code: ML/MR

* Be sure to specify either "ML" or "MR" for the side-mounted motor type.

RCP4-SA5R/SA6R/SA7R/RA5R/RA6R

The motor side-mounted direction can be specified. ML and MR represent the left and right, respectively, as viewed from the motor side of the actuator.





Non-motor end specification
Option code: NM

All models

Description

Select this option if you want to change the home position of the actuator slider or rod from the normal position (motor end) to the front end.

Flange
Option code: FL



Scraper
Option code: SC

RCP4-RA5C/RA6C/RA5R/RA6R

Description

When a rod actuator is used, select this option if you want to prevent dust attached to the rod from entering the actuator.

Slider roller specification
Option code: SR

RCP4-SA5C/SA6C/SA7C/SA5R/SA6R/SA7R

The slider of the standard slider type specification is changed to the same roller structure of the cleanroom specification.

When the slider roller specification is selected, the appearance and dimensions of the slider cover become the same as those of the cleanroom specification.

Vacuum joint on opposite side
Option code: VR

RCP4CR-SA5C/SA6C/SA7C

The standard specification is that the vacuum joint is installed on the left side of the actuator as viewed from the motor side. This option changes the vacuum joint position to the right side (opposite side).

RCP4-SA5C


ROBO Cylinder, Slider Type, Motor Unit Coupled, Actuator Width 52mm, 24-V Pulse Motor

Model Specification Items	RCP4	—	SA5C	—	I	—	42P	—	□	—	□	—	P3	—	□	—	□
Series	—	Type	—	Encoder type	—	Motor type	—	Lead	—	Stroke	—	Applicable controller	—	Cable length	—	Options	
I: Incremental specification							42P: Pulse motor, size 42□	20: 20mm 12: 12mm 6: 6mm 3: 3mm	50: 50mm 800: 800mm (every 50mm)	P3: PCON-CA MSEP-C	N: None P: 1m S: 3m M: 5m X□□: Specified length R□□: Robot cable					Refer to the options table below.	




- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop.
- (*The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P. 37 to 40.
- (2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)

■ Correlation Diagrams of Speed and Payload



RCP4-SA5C Horizontal, MSEP connected



Actuator Specifications

■ Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload	Stroke (mm)
			Horizontal (kg) Vertical (kg)	
RCP4-SA5C-I-42P-20-[①]-P3-[②]-[③]	20	PCON-CA MSEP-C	6.5 4 0.5 (*)	1
RCP4-SA5C-I-42P-12-[①]-P3-[②]-[③]	12	PCON-CA MSEP-C	9 6 2.5	2.5
RCP4-SA5C-I-42P-6-[①]-P3-[②]-[③]	6	PCON-CA MSEP-C	18 13 6	6
RCP4-SA5C-I-42P-3-[①]-P3-[②]-[③]	3	PCON-CA MSEP-C	20 16 12	12
				50~800 (every 50mm)

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2G

■ Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	550 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)
20	PCON-CA	1440 <1280>		1225	1045	900	785	690	610
	MSEP-C		960			900	785	690	610
12	PCON-CA	900	795	665	570	490	425	375	330
	MSEP-C		600			570	490	425	375
6	PCON-CA	450	395	335	285	245	215	185	165
	MSEP-C		300			285	245	215	185
3	PCON-CA	225	195	165	140	120	105	90	80
	MSEP-C		150			140	120	105	90

The values in <> apply when the actuator is used vertically.

(unit: mm/s)

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
Special length	M (5m)	—
	X06 (6m) ~X10 (10m)	—
Robot cable	X11 (11m) ~X15 (15m)	—
	X16 (16m) ~X20 (20m)	—
Robot cable	R01 (1m) ~R03 (3m)	—
	R04 (4m) ~R05 (5m)	—
	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (right)	CJR	P8	—
Optional cable exit direction (left)	CJL	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Non-motor end specification	NM	P8	—
Slider roller specification	SR	P8	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø10mm, rolled C10
Positioning repeatability (*)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Guide	Linear guide
Dynamic allowable moment (*)	Ma: 4.9 N·m, Mb: 6.8 N·m, Mc: 11.7 N·m
Allowable overhang	150mm or less in Ma, Mb and Mc directions
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)

(*) The value at lead 20 is shown in []. (**) Based on 5,000km of traveling life


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com

2D
CAD

- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L	Without brake	279	329	379	429	479	529	579	629	679	729	779	829	879	929	979	1029
	With brake	319	369	419	469	519	569	619	669	719	769	819	869	919	969	1019	1069
A		73	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800
B		0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7
C		0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7
D		4	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18
F		4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18
G		166	216	266	316	366	416	466	516	566	616	666	716	766	816	866	916
H		0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
J		0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785
K		181	231	281	331	381	431	481	531	581	631	681	731	781	831	881	931
Mass (kg)	Without brake	1.5	1.6	1.8	1.9	2.1	2.2	2.4	2.5	2.6	2.8	2.9	3.1	3.2	3.4	3.5	3.7
	With brake	1.7	1.9	2.0	2.1	2.3	2.4	2.6	2.7	2.9	3.0	3.2	3.3	3.5	3.6	3.7	3.9

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PN-□-0-□	Positioner type based on PIO control				—	
Field network type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver				—	
Positioner multi-axis specification PIO type		PCON-CA-42PI-PLP-□-0-□	Pulse-train input type				—	Refer to the MSEP catalog.
Positioner multi-axis specification Network type		MSEP-C-□～NP-□-0-□	Equipped with a high-output driver				Refer to the MSEP catalog.	
		MSEP-C-□～PN-□-0-□	Supporting 7 major field networks	768 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.
		MSEP-C-□～△-0-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.
		MSEP-C-□～△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4-SA6C


ROBO Cylinder, Slider Type, Motor Unit Coupled, Actuator Width 58 mm, 24-V Pulse Motor

Model Specification Items	RCP4	—	SA6C	—	I	—	42P	—	[]	—	[]	—	P3	—	[]	—	[]
Series	—	Type	—	Encoder type	—	Motor type	—	Lead	—	Stroke	—	Applicable controller	—	Cable length	—	Options	
I: Incremental specification				42P: Pulse motor, size 42□				20: 20mm 12: 12mm 6: 6mm 3: 3mm	—	50: 50mm 800: 800mm (every 50mm)	—	P3: PCON-CA MSEP-C		N: None P: 1 m S: 3 m M: 5 m X□□: Specified length R□□: Robot cable		Refer to the options table below.	



- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop.
(*)The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P.37 to 40.
- (2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)

■ Correlation Diagrams of Speed and Payload



Actuator Specifications

■ Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload		Stroke (mm)
			Horizontal (kg)	Vertical (kg)	
RCP4-SA6C-I-42P-20-[①]-P3-[②]-[③]	20	PCON-CA	10	1	50~800 (every 50mm)
		MSEP-C	6	0.5 (*)	
RCP4-SA6C-I-42P-12-[①]-P3-[②]-[③]	12	PCON-CA	15	2.5	
		MSEP-C	8.5	2	
RCP4-SA6C-I-42P-6-[①]-P3-[②]-[③]	6	PCON-CA	25	6	
		MSEP-C	15	5	
RCP4-SA6C-I-42P-3-[①]-P3-[②]-[③]	3	PCON-CA	25	12	
		MSEP-C	19	10	

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2 G

■ Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	550 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)
20	PCON-CA	1440 <1280>	1230	1045	905	785	690	615	
	MSEP-C	960		905	785	690	615		
12	PCON-CA	900	795	670	570	490	430	375	335
	MSEP-C	600		570	490	430	375	335	
6	PCON-CA	450	395	335	285	245	215	185	165
	MSEP-C	300		285	245	215	185	165	
3	PCON-CA	225	195	165	140	120	105	90	80
	MSEP-C	150		140	120	105	90	80	

The values in <> apply when the actuator is used vertically.

(unit: mm/s)

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
	M (5m)	—
Special length	X06 (6m) ~X10 (10m)	—
	X11 (11m) ~X15 (15m)	—
	X16 (16m) ~X20 (20m)	—
	R01 (1m) ~R03 (3m)	—
Robot cable	R04 (4m) ~R05 (5m)	—
	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (right)	CJR	P8	—
Optional cable exit direction (left)	CJL	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Non-motor end specification	NM	P8	—
Slider roller specification	SR	P8	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø10mm, rolled C10
Positioning repeatability (*1)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Guide	Linear guide
Dynamic allowable moment (*2)	Ma: 8.9 N·m, Mb: 12.7 N·m, Mc: 18.6 N·m
Allowable overhang	220mm or less in Ma, Mb and Mc directions
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)


(*1) The value at lead 20 is shown in []. (*2) Based on 5,000km of traveling life

Dimensional Drawings

CAD drawings can be downloaded from the website. www.intelligentactuator.com



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L Without brake	299.5	349.5	399.5	449.5	499.5	549.5	599.5	649.5	699.5	749.5	799.5	849.5	899.5	949.5	999.5	1049.5	
With brake	339.5	389.5	439.5	489.5	539.5	589.5	639.5	689.5	739.5	789.5	839.5	889.5	939.5	989.5	1039.5	1089.5	
A	0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	
D	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	
E	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G	186.5	236.5	286.5	336.5	386.5	436.5	486.5	536.5	586.5	636.5	686.5	736.5	786.5	836.5	886.5	936.5	
H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K	201.5	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5	
Mass (kg)	Without brake	2.0	2.1	2.3	2.4	2.6	2.7	2.9	3.0	3.2	3.4	3.5	3.7	3.8	4.0	4.1	4.3
	With brake	2.2	2.3	2.5	2.6	2.8	3.0	3.1	3.3	3.4	3.6	3.7	3.9	4.1	4.2	4.4	4.5

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□～NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□～△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4-SA7C


ROBO Cylinder, Slider Type, Motor Unit Coupled, Actuator Width 73mm, 24-V Pulse Motor

Model Specification Items	RCP4 — SA7C — I — 56P —	Lead	Stroke	P3	Cable length	Options
Series	—	Type	— Encoder type	— Motor type	—	—
I: Incremental specification	56P: Pulse motor, size 56□	24: 24mm 16: 16mm 8: 8mm 4: 4mm	50: 50mm 80: 80mm (every 50mm)	P3: PCON-CA MSEP-C	N: None P: 1m S: 3m M: 5m X□□: Specified length R□□: Robot cable	Refer to the options table below.




- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop.
(*)The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P.37 to 40.
(2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)

■ Correlation Diagrams of Speed and Payload



RCP4-SA7C Horizontal, MSEP connected



Actuator Specifications

■ Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload	Stroke (mm)
			Horizontal (kg)	Vertical (kg)
RCP4-SA7C-I-56P-24-①-P3-②-③	24	PCON-CA	20	3
		MSEP-C	18	2 (*)
RCP4-SA7C-I-56P-16-①-P3-②-③	16	PCON-CA	40	8
		MSEP-C	35	5 (*)
RCP4-SA7C-I-56P-8-①-P3-②-③	8	PCON-CA	45	16
		MSEP-C	40	10 (*)
RCP4-SA7C-I-56P-4-①-P3-②-③	4	PCON-CA	45	25
		MSEP-C	40 (*)	15 (*)

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2G

■ Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	500 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)
24	PCON-CA	1200			1155	1010	890	790	
	MSEP-C		1000<800>				890<800>	790	
16	PCON-CA	980<840>	865<840>	750	655	580	515		
	MSEP-C		560						
8	PCON-CA	490	430	375	325	290	255		
	MSEP-C		280						
4	PCON-CA	245<210>	215<210>	185	160	145	125		
	MSEP-C		140						

The values in <> apply when the actuator is used vertically.

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
Special length	M (5m)	—
	X06 (6m) ~X10 (10m)	—
	X11 (11m) ~X15 (15m)	—
Robot cable	X16 (16m) ~X20 (20m)	—
	R01 (1m) ~R03 (3m)	—
	R04 (4m) ~R05 (5m)	—
	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (right)	CJR	P8	—
Optional cable exit direction (left)	CJL	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Non-motor end specification	NM	P8	—
Slider roller specification	SR	P8	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø12mm, rolled C10
Positioning repeatability (*)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Guide	Linear guide
Dynamic allowable moment (*)	Ma: 13.9 N·m, Mb: 19.9 N·m, Mc: 38.3 N·m
Allowable overhang	230mm or less in Ma, Mb and Mc directions
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)


(*) The value at lead 24 is shown in []. (*2) Based on 5,000km of traveling life

Dimensional Drawings

CAD drawings can be downloaded from the website. www.intelligentactuator.com



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L Without brake	352.5	402.5	452.5	502.5	552.5	602.5	652.5	702.5	752.5	802.5	852.5	902.5	952.5	1002.5	1052.5	1102.5	
With brake	402.5	452.5	502.5	552.5	602.5	652.5	702.5	752.5	802.5	852.5	902.5	952.5	1002.5	1052.5	1102.5	1152.5	
A	0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	
D	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	
E	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G	199	249	299	349	399	449	499	549	599	649	699	749	799	849	899	949	
H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K	219.5	269.5	319.5	369.5	419.5	469.5	519.5	569.5	619.5	669.5	719.5	769.5	819.5	869.5	919.5	969.5	
Mass (kg)	Without brake	3.4	3.6	3.8	4.1	4.3	4.6	4.8	5.1	5.3	5.6	5.8	6.0	6.3	6.5	6.8	7.0
	With brake	3.9	4.1	4.3	4.6	4.8	5.1	5.3	5.6	5.8	6.1	6.3	6.5	6.8	7.0	7.3	7.5

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-56PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-56PI-PN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-56PI-PLP-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□～NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□～△-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points			Refer to the MSEP catalog.	

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4-SA5R

ROBO Cylinder, Slider Type, Side-mounted Motor Type, Actuator Width 52mm, 24-V Pulse Motor

Model Specification Items	RCP4	— SA5R —	I	— 42P —	□	— □ —	P3	— □ —	□	— Options
Series	—	Type	— Encoder type —	Motor type	Lead	— Stroke —	Applicable controller	Cable length	—	
I: Incremental specification			42P: Pulse motor, size 42□	20: 20mm 12: 12mm 6: 6mm 3: 3mm	50: 50mm 800: 800mm (every 50mm)	P3: PCON-CA MSEP-C	N: None P: 1m S: 3m M: 5m X□□: Specified length R□□: Robot cable			Refer to the options table below. *Be sure to specify either "ML" or "MR" as the motor side-mounted direction.




The "Motor side-mounted to the left (ML)" option is selected for the actuator shown above.




- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1G (*). Note that raising the acceleration causes the payload to drop.
(*)The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P.37 to 40.
- (2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)


■ Correlation Diagrams of Speed and Payload



RCP4-SA5R Horizontal, PCON-CA connected



RCP4-SA5R Vertical, PCON-CA connected



Actuator Specifications

■ Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload	Stroke (mm)
			Horizontal (kg) Vertical (kg)	
RCP4-SA5R-I-42P-20-[①]-P3-[②]-[③]	20	PCON-CA MSEP-C	6.5 4 0.5 (*)	
RCP4-SA5R-I-42P-12-[①]-P3-[②]-[③]	12	PCON-CA MSEP-C	9 6 2.5	
RCP4-SA5R-I-42P-6-[①]-P3-[②]-[③]	6	PCON-CA MSEP-C	18 13 6	50~800 (every 50mm)
RCP4-SA5R-I-42P-3-[①]-P3-[②]-[③]	3	PCON-CA MSEP-C	20 16 12	

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2G

■ Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	550 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)
20	PCON-CA	1440 <1120>	1225<1120>	1045	900	785	690	610	
	MSEP-C	960<800>			900<800>	785	690	610	
12	PCON-CA	900<800>	795	665	570	490	425	375	330
	MSEP-C		600		570	490	425	375	330
6	PCON-CA	450	395	335	285	245	215	185	165
	MSEP-C		300		285	245	215	185	165
3	PCON-CA	225	195	165	140	120	105	90	80
	MSEP-C		150		140	120	105	90	80

The values in < > apply when the actuator is used vertically.

(unit: mm/s)

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
	M (5m)	—
Special length	X06 (6m) ~X10 (10m)	—
	X11 (11m) ~X15 (15m)	—
	X16 (16m) ~X20 (20m)	—
	R01 (1m) ~R03 (3m)	—
	R04 (4m) ~R05 (5m)	—
Robot cable	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (outside)	CJO	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Motor side-mounted to the left (standard)	ML	P8	—
Motor side-mounted to the right	MR	P8	—
Non-motor end specification	NM	P8	—
Slider roller specification	SR	P8	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø10mm, rolled C10
Positioning repeatability (*1)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Guide	Linear guide
Dynamic allowable moment (*2)	Ma: 4.9 N·m, Mb: 6.8 N·m, Mc: 11.7 N·m
Allowable overhang	150mm or less in Ma, Mb and Mc directions
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)

(*1) The value at lead 20 is shown in []. (*2) Based on 5,000km of traveling life.


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com

2D
CAD

- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L	208.5	258.5	308.5	358.5	408.5	458.5	508.5	558.5	608.5	658.5	708.5	758.5	808.5	858.5	908.5	958.5	
A	73	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C	0	0	1	1	2	2	3	3	4	4	5	5	6	67	7	8	
D	4	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	
F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G	166	216	266	316	366	416	466	516	566	616	666	716	766	816	866	916	
H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K	181	231	281	331	381	431	481	531	581	631	681	731	781	831	881	931	
Mass (kg)	Without brake	1.7	1.9	2.0	2.2	2.3	2.5	2.6	2.8	2.9	3.0	3.2	3.3	3.5	3.6	3.8	3.9
	With brake	2.0	2.1	2.3	2.4	2.5	2.7	2.8	3.0	3.1	3.3	3.4	3.6	3.7	3.9	4.0	4.1

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□～NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□～△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4-SA6R

ROBO Cylinder, Slider Type, Side-mounted Motor Type, Actuator Width 58mm, 24-V Pulse Motor

Model Specification Items	RCP4	— SA6R —	I	— 42P —	□	— Lead —	□	— Stroke —	P3	— Applicable controller —	□	— Cable length —	□	— Options —
	Series	— Type	Encoder type	Motor type										
			I: Incremental specification	42P: Pulse motor, size 42□	20: 20mm 12: 12mm 6: 6mm 3: 3mm	50: 50mm 800: 800mm (every 50mm)		P3: PCON-CA MSEP-C		N: None P: 1m S: 3m M: 5m X□□: Specified length R□□: Robot cable				Refer to the options table below. * Be sure to specify either "ML" or "MR" as the motor side-mounted direction.




The "Motor side-mounted to the left (ML)" option is selected for the actuator shown above.




- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop.
(*The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P. 37 to 40.)
(2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)

Correlation Diagrams of Speed and Payload



RCP4-SA6R Horizontal, PCON-CA connected



RCP4-SA6R Vertical, PCON-CA connected

Actuator Specifications

Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload		Stroke (mm)
			Horizontal (kg)	Vertical (kg)	
RCP4-SA6R-I-42P-20-[①]-P3-[②]-[③]	20	PCON-CA	10	1	50~800 (every 50mm)
		MSEP-C	6	0.5 (*)	
RCP4-SA6R-I-42P-12-[①]-P3-[②]-[③]	12	PCON-CA	15	2.5	
		MSEP-C	8.5	2	
RCP4-SA6R-I-42P-6-[①]-P3-[②]-[③]	6	PCON-CA	25	6	
		MSEP-C	15	5	
RCP4-SA6R-I-42P-3-[①]-P3-[②]-[③]	3	PCON-CA	25	12	
		MSEP-C	19	10	

Code explanation [①] Stroke [②] Cable length [③] Options (*) When operated at 0.2G

Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	550 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)
20	PCON-CA	1280	1230	1045	905	785	690	615	
	MSEP-C		960		905	785	690	615	
12	PCON-CA	900	795	670	570	490	430	375	335
	MSEP-C		600		570	490	430	375	335
6	PCON-CA	450	395	335	285	245	215	185	165
	MSEP-C		300		285	245	215	185	165
3	PCON-CA	225	195	165	140	120	105	90	80
	MSEP-C		150		140	120	105	90	80

The values in < > apply when the actuator is used vertically.

(unit: mm/s)

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (outside)	CJO	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Motor side-mounted to the left (standard)	ML	P8	—
Motor side-mounted to the right	MR	P8	—
Non-motor end specification	NM	P8	—
Slider roller specification	SR	P8	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
Special length	M (5m)	—
	X06 (6m) ~X10 (10m)	—
Robot cable	X11 (11m) ~X15 (15m)	—
	X16 (16m) ~X20 (20m)	—
R01 (1m) ~R03 (3m)	R01 (1m) ~R03 (3m)	—
	R04 (4m) ~R05 (5m)	—
R06 (6m) ~R10 (10m)	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
R16 (16m) ~R20 (20m)	R16 (16m) ~R20 (20m)	—
	R17 (17m) ~R21 (21m)	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø10mm, rolled C10
Positioning repeatability (*1)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Guide	Linear guide
Dynamic allowable moment (*2)	Ma: 8.9 N·m, Mb: 12.7 N·m, Mc: 18.6 N·m
Allowable overhang	220mm or less in Ma, Mb and Mc directions
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)

(*1) The value at lead 20 is shown in []. (*2) Based on 5,000km of traveling life


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com

2D
CAD

- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L	229	279	329	379	429	479	529	579	629	679	729	779	829	879	929	979	
A	0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	
D	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	
E	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G	186.5	236.5	286.5	336.5	386.5	436.5	486.5	536.5	586.5	636.5	686.5	736.5	786.5	836.5	886.5	936.5	
H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K	201.5	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5	
Mass (kg)	Without brake	2.2	2.4	2.5	2.7	2.8	3.0	3.1	3.3	3.5	3.6	3.8	3.9	4.1	4.2	4.4	4.6
	With brake	2.4	2.6	2.7	2.9	3.1	3.2	3.4	3.5	3.7	3.8	4.0	4.2	4.3	4.5	4.6	4.8

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PN-□-0-□	Positioner type based on PIO control				—	
Field network type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver				—	
		PCON-CA-42PI-PLP-□-0-□	Pulse-train input type				—	
Positioner multi-axis specification PIO type		PCON-CA-42PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks				—	
Positioner multi-axis specification Network type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)				Refer to the MSEP catalog.	Refer to the MSEP catalog.
		MSEP-C-□-~PN-□-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
		MSEP-C-□-~△-0-0-□		256 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
L	252.5	302.5	352.5	402.5	452.5	502.5	552.5	602.5	652.5	702.5	752.5	802.5	852.5	902.5	952.5	1002.5	
A	0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	
D	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	
E	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G	199	249	299	349	399	449	499	549	599	649	699	749	799	849	899	949	
H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K	219.5	269.5	319.5	369.5	419.5	469.5	519.5	569.5	619.5	669.5	719.5	769.5	819.5	869.5	919.5	969.5	
Mass (kg)	Without brake	3.8	4.0	4.3	4.5	4.8	5.0	5.3	5.5	5.7	6.0	6.2	6.5	6.7	7.0	7.2	7.4
	With brake	4.3	4.5	4.8	5.0	5.3	5.5	5.8	6.0	6.2	6.5	6.7	7.0	7.2	7.5	7.7	8.0

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-56PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-56PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-56PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□～NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□～△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com




- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.
- *3 The direction of width across flats varies depending on the product.
- *4 If the actuator is installed using the front housing and flange, make sure the actuator will not receive any external force.
(For details, refer to "Notes on Installing Rod Actuators" on P.35.)



Rod Deflection of RCP4-RA5C (Reference Values)

(The graph below plots deflection as measured by installing the actuator vertically and applying a force to the rod from one side.)



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400
	L Without brake	300	350	400	450	500	550	600
A With brake	340	390	440	490	540	590	640	690
B	73.5	123.5	173.5	223.5	273.5	323.5	373.5	423.5
C	0	0	1	1	2	2	3	3
D	0	0	0	1	1	2	2	3
F	4	4	6	6	8	8	10	10
G	127	177	227	277	327	377	427	477
J	18.5	68.5	118.5	168.5	218.5	268.5	318.5	368.5
K	153.5	203.5	253.5	303.5	353.5	403.5	453.5	503.5
M	73.5	123.5	173.5	223.5	273.5	323.5	373.5	423.5
N	35	85	135	185	135	85	135	85
Allowable static load at end of rod (N)	65.6	51.2	41.7	34.9	29.8	25.7	22.4	19.7
Allowable dynamic load at end of rod (N)	32.4	23.6	18.1	14.4	11.6	9.5	7.7	6.2
Load offset 0mm	25.6	19.7	15.7	12.7	10.4	8.6	7.1	5.7
Load offset 100mm	6.6	5.2	4.3	3.7	3.2	2.8	2.6	2.3
Allowable static torque at end of rod (N·m)	2.6	2.0	1.6	1.3	1.0	0.9	0.7	0.6
Mass (kg)	Without brake	1.9	2.1	2.4	2.7	2.9	3.2	3.4
	With brake	2.1	2.4	2.6	2.9	3.1	3.4	3.7
								3.9

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-PLP-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□-~△-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				


* In the model numbers shown above, □ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4-RA6C

ROBO Cylinder, Rod Type, Motor Unit Coupled, Actuator Width 61mm, 24-V Pulse Motor

Model Specification Items	RCP4	—	RA6C	—	I	—	56P	—	□	—	□	—	P3	—	□	—	□
Series	—	Type	—	Encoder type	—	Motor type	—	Lead	—	Stroke	—	Applicable controller	—	Cable length	—	Options	
I: Incremental specification				56P: Pulse motor, size 56□				24: 24mm	50: 50mm	P3: PCON-CA		N: None					
								16: 16mm	8: 8mm	MSEP-C		P: 1m					
								8: 8mm	500: 500mm (every 50mm)			S: 3 m					
								4: 4mm				M: 5 m					
										X□□: Specified length							
										R□□: Robot cable						Refer to the options table below.	


Built-in guide mechanism




POINT Notes on selection	(1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop. (*) The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P. 37 to 40. (2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.) (3) All horizontal payloads are values when an external guide is used.
------------------------------------	--

Correlation Diagrams of Speed and Payload


* The values of the horizontal specification assume that an external guide is used.



RCP4-RA6C Horizontal, PCON-CA connected



RCP4-RA6C Vertical, MSEP connected



RCP4-RA6C Vertical, MSEP connected

Actuator Specifications

Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload Horizontal (kg)	Maximum payload Vertical (kg)	Max. push force (N)	Stroke (mm)
RCP4-RA6C-I-56P-24-①-P3-②-③	24	PCON-CA	20	3	182	50~500 (every 50mm)
		MSEP-C	18	3 (*)		
RCP4-RA6C-I-56P-16-①-P3-②-③	16	PCON-CA	50	8	273	
		MSEP-C	40 (*)	5 (*)		
RCP4-RA6C-I-56P-8-①-P3-②-③	8	PCON-CA	60	18	547	
		MSEP-C	50 (*)	17.5 (*)		
RCP4-RA6C-I-56P-4-①-P3-②-③	4	PCON-CA	80	28	1094	
		MSEP-C	55 (*)	26 (*)		

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2 G

Stroke and Maximum Speed

Lead (mm)	Connected controller	50~500 (every 50mm)
24	PCON-CA	800<600>
	MSEP-C	600<400>
16	PCON-CA	700<560>
	MSEP-C	420
8	PCON-CA	420
	MSEP-C	210
4	PCON-CA	210
	MSEP-C	140

The values in <> apply when the actuator is used vertically. (unit: mm/s)

① Stroke

Stroke (mm)	Standard price
50	—
100	—
150	—
200	—
250	—
300	—
350	—
400	—
450	—
500	—

② Cable Length

Type	Cable symbol	Standard price
Standard type	P (1m)	—
	S (3m)	—
	M (5m)	—
Special length	X06 (6m) ~X10 (10m)	—
	X11 (11m) ~X15 (15m)	—
	X16 (16m) ~X20 (20m)	—
	R01 (1m) ~R03 (3m)	—
	R04 (4m) ~R05 (5m)	—
Robot cable	R06 (6m) ~R10 (10m)	—
	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (right)	CJR	P8	—
Optional cable exit direction (left)	CJL	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Flange bracket	FL	P8	—
Non-motor end specification	NM	P8	—
Scraper	SC	P8	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø12 mm, rolled C10
Positioning repeatability (*)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Rod	Ø25mm stainless steel pipe
Rod non-rotation precision	±0 deg
Allowable rod load mass	Refer to P. 24 and P. 36
Rod tip overhang distance	100mm or less
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)



(*) The value at lead 20 is shown in [].

Dimensional Drawings

CAD drawings can be downloaded from the website. www.intelligentactuator.com




- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.
- *3 The direction of width across flats varies depending on the product.
- *4 If the actuator is installed using the front housing and flange, make sure the actuator will not receive any external force.
(For details, refer to "Notes on Installing Rod Actuators" on P. 35.)



■ Rod Deflection of RCP4-RA6C (Reference Values)

(The graph below plots deflection as measured by installing the actuator vertically and applying a radial force to the rod from one side.)



■ Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500
	Without brake	With brake								
L	368.5	418.5	468.5	518.5	568.5	618.5	668.5	718.5	768.5	818.5
A	76	126	176	226	276	326	376	426	476	526
B	0	0	1	1	2	2	3	3	4	4
C	0	0	0	1	1	2	2	3	3	4
D	4	4	6	6	8	8	10	10	12	12
F	6	6	6	8	8	10	10	12	12	14
G	146	196	246	296	346	396	446	496	546	596
J	91	141	191	241	291	341	391	441	491	541
K	181.5	231.5	281.5	331.5	381.5	431.5	481.5	531.5	581.5	631.5
M	76	126	176	126	76	126	76	126	76	126
N	30	80	130	80	130	80	130	80	130	80
Allowable static load at end of rod (N)	112.7	91.5	76.7	65.7	57.2	50.4	44.8	40.2	36.2	32.7
Allowable dynamic load at end of rod (N)	49.0	37.4	29.9	24.5	20.4	17.1	14.5	12.3	10.3	8.6
Allowable static torque at end of rod (N·m)	11.4	9.3	7.9	6.8	6.0	5.4	4.9	4.5	4.1	3.8
Allowable dynamic torque at end of rod (N·m)	3.9	3.1	2.5	2.1	1.8	1.5	1.3	1.1	1.0	0.8
Mass (kg)	Without brake	3.4	3.7	4.1	4.4	4.7	5.0	5.4	5.7	6.0
	With brake	3.9	4.2	4.6	4.9	5.2	5.5	5.9	6.2	6.5

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-56PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-56PI-PN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-56PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□-~-△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				


* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

Dimensional Drawings

CAD drawings can be downloaded from the website.




- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.
- *3 The direction of width across flats varies depending on the product.
- *4 If the actuator is installed using the front housing and flange, make sure the actuator will not receive any external force.
(For details, refer to "Notes on Installing Rod Actuators" on P. 35.)



*The dimensions in () apply when a brake is equipped.

■ Rod Deflection of RCP4-RA5R (Reference Values)

(The graph below plots deflection as measured by installing the actuator vertically and applying a radial force to the rod from one side.)



■ Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400
L	181	231	281	331	381	431	481	531
A	73.5	123.5	173.5	223.5	273.5	323.5	373.5	423.5
B	0	0	1	1	2	2	3	3
C	0	0	0	1	1	2	2	3
D	4	4	6	6	8	8	10	10
F	4	4	4	6	6	8	8	10
G	127	177	227	277	327	377	427	477
J	18.5	68.5	118.5	168.5	218.5	268.5	318.5	368.5
K	153.5	203.5	253.5	303.5	353.5	403.5	453.5	503.5
M	73.5	123.5	173.5	223.5	273.5	323.5	373.5	423.5
N	35	85	135	85	135	85	135	85
Allowable static load at end of rod (N)	65.6	51.2	41.7	34.9	29.8	25.7	22.4	19.7
Allowable dynamic load at end of rod (N) Load offset 0mm	32.4	23.6	18.1	14.4	11.6	9.5	7.7	6.2
Load offset 100mm	25.6	19.7	15.7	12.7	10.4	8.6	7.1	5.7
Allowable static torque at end of rod (Nm)	6.6	5.2	4.3	3.7	3.2	2.8	2.6	2.3
Allowable dynamic torque at end of rod (N·m)	2.6	2.0	1.6	1.3	1.0	0.9	0.7	0.6
Mass (kg)	2.1	2.4	2.6	2.9	3.2	3.4	3.7	4.0
	Without brake	2.3	2.6	2.9	3.1	3.4	3.7	4.2

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-△-0-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□～NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points		Refer to the MSEP catalog.	Refer to the MSEP catalog.	Refer to the MSEP catalog.
Positioner multi-axis specification Network type		MSEP-C-□～△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				

* In the model numbers shown above, □ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).


Dimensional Drawings

CAD drawings can be downloaded from the website.

www.intelligentactuator.com




- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.
- *3 The direction of width across flats varies depending on the product.
- *4 If the actuator is installed using the front housing and flange, make sure the actuator will not receive any external force.
(For details, refer to "Notes on Installing Rod Actuators" on P. 35.)



Rod Deflection of RCP4-RA6R (Reference Values)

(The graph below plots deflection as measured by installing the actuator vertically and applying a radial force to the rod from one side.)



Dimensions and Mass by Stroke

Stroke	50	100	150	200	250	300	350	400	450	500	
L	214.5	264.5	314.5	364.5	414.5	464.5	514.5	564.5	614.5	664.5	
A	76	126	176	226	276	326	376	426	476	526	
B	0	0	1	1	2	2	3	3	4	4	
C	0	0	0	1	1	2	2	3	3	4	
D	4	4	6	6	8	8	10	10	12	12	
F	6	6	6	8	8	10	10	12	12	14	
G	146	196	246	296	346	396	446	496	546	596	
J	91	141	191	241	291	341	391	441	491	541	
K	181.5	231.5	281.5	331.5	381.5	431.5	481.5	531.5	581.5	631.5	
M	76	126	176	226	276	326	376	426	476	526	
N	30	80	130	80	130	80	130	80	130	80	
Allowable static load at end of rod (N)	112.7	91.5	76.7	65.7	57.2	50.4	44.8	40.2	36.2	32.7	
Allowable dynamic load at end of rod (N)	49.0	37.4	29.9	24.5	20.4	17.1	14.5	12.3	10.3	8.6	
Allowable static torque at end of rod (N·m)	11.4	9.3	7.9	6.8	6.0	5.4	4.9	4.5	4.1	3.8	
Allowable dynamic torque at end of rod (N·m)	3.9	3.1	2.5	2.1	1.8	1.5	1.3	1.1	1.0	0.8	
Mass (kg)	Without brake	3.9	4.2	4.5	4.8	5.1	5.5	5.8	6.1	6.4	6.8
	With brake	4.4	4.7	5.0	5.3	5.6	6.0	6.3	6.6	6.9	7.3

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-56PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-56PI-PN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-56PI-PLN-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points	Refer to the MSEP catalog.			
Positioner multi-axis specification Network type		MSEP-C-□-~△-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points				

* In the model numbers shown above, □ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

RCP4CR-SA5C


Cleanroom ROBO Cylinder, Slider Type, Motor Unit Coupled, Actuator Width 52mm, 24-V Pulse Motor

Model Specification Items	RCP4CR-SA5C	I	—	42P	—	□ — □ — □ — □ — □ — □	P3	—	□ — □ — □	— Options	
Series	—	Type	—	Encoder type	—	Motor type	—	Lead	—	Stroke	— Applicable controller
I: Incremental specification	42P: Pulse motor, size 42□	20: 20mm	50: 50mm	P3: PCON-CA	—	N: None	Lead	12: 12mm	800: 800mm (every 50mm)	P: 1m	Refer to the options table below.
		6: 6mm	Lead 6	MSEP-C	—	S: 3m		3: 3mm		M: 5m	
					X□: Specified length					X□□: Robot cable	




- (1) The maximum payload is the value when operated at 0.3G (0.2G with some models) acceleration. The upper limit of acceleration is 1 G (*). Note that raising the acceleration causes the payload to drop.
(*)The specific value varies depending on the connected controller and actuator lead. For details, refer to "Selection References" on P. 37 to 40.
(2) Take note that the maximum payload and maximum speed vary depending on the controller connected to the RCP4. (Refer to the actuator specifications below.)

Correlation Diagrams of Speed and Payload



RCP4CR-SA5C Horizontal, PCON-CA connected

RCP4CR-SA5C Vertical, PCON-CA connected



RCP4CR-SA5C Horizontal, MSEP connected

RCP4CR-SA5C Vertical, MSEP connected

Actuator Specifications

Leads and Payloads

Model number	Lead (mm)	Connected controller	Maximum payload Horizontal (kg)	Vertical (kg)	Stroke (mm)	50~800 (every 50mm)
RCP4CR-SA5C-I-42P-20-[①]-P3-[②]-[③]	20	PCon-CA	6.5	1		
		MSEP-C	4	0.5 (*)		
RCP4CR-SA5C-I-42P-12-[①]-P3-[②]-[③]	12	PCon-CA	9	2.5		
		MSEP-C	6	2		
RCP4CR-SA5C-I-42P-6-[①]-P3-[②]-[③]	6	PCon-CA	18	6		
		MSEP-C	13	5		
RCP4CR-SA5C-I-42P-3-[①]-P3-[②]-[③]	3	PCon-CA	20	12		
		MSEP-C	16	10		

Code explanation ① Stroke ② Cable length ③ Options (*) When operated at 0.2G

Stroke and Maximum Speed

Lead (mm)	Connected controller	50~450 (every 50mm)	500 (mm)	550 (mm)	600 (mm)	650 (mm)	700 (mm)	750 (mm)	800 (mm)	Suction amount (Nl/min)
20	PCon-CA	1440 <1280>	1225	1045	900	785	690	610		80
	MSEP-C		960		900	785	690	610		
12	PCon-CA	900	795	665	570	490	425	375	330	50
	MSEP-C		600		570	490	425	375	330	
6	PCon-CA	450	395	335	285	245	215	185	165	30
	MSEP-C		300		285	245	215	185	165	
3	PCon-CA	225	195	165	140	120	105	90	80	15
	MSEP-C		150		140	120	105	90	80	

The values in <> apply when the actuator is used vertically. (unit: mm/s)

① Stroke

Stroke (mm)	Standard price	Stroke (mm)	Standard price
50	—	450	—
100	—	500	—
150	—	550	—
200	—	600	—
250	—	650	—
300	—	700	—
350	—	750	—
400	—	800	—

③ Options

Name	Option code	See page	Standard price
Brake	B	P8	—
Optional cable exit direction (top)	CJT	P8	—
Optional cable exit direction (right)	CJR	P8	—
Optional cable exit direction (left)	CJL	P8	—
Optional cable exit direction (bottom)	CJB	P8	—
Non-motor end specification	NM	P8	—
Vacuum joint on opposite side	VR	P8	—

② Cable Length

Type	Cable symbol		Standard price
	P (1m)	S (3m)	
Standard type		M (5m)	—
	X06 (6m) ~X10 (10m)	X11 (11m) ~X15 (15m)	—
Special length	X16 (16m) ~X20 (20m)	R01 (1m) ~R03 (3m)	—
		R04 (4m) ~R05 (5m)	—
Robot cable	R06 (6m) ~R10 (10m)	R11 (11m) ~R15 (15m)	—
	R16 (16m) ~R20 (20m)	R17 (17m) ~R22 (22m)	—

Actuator Specifications

Item	Description
Drive system	Ball screw Ø10 mm, rolled C10
Positioning repeatability (*)	±0.02mm [±0.03mm]
Lost motion	0.1mm or less
Base	Material: Aluminum with white alumite treatment
Dynamic allowable moment (*)	Ma: 4.9 N·m, Mb: 6.8 N·m, Mc: 11.7 N·m
Allowable overhang	150 mm or less in Ma, Mb and Mc directions
Grease	Low dust generation grease (urea grease) is used for both ball screws and guides.
Cleanliness	Class 10 (0.1 μm)
Ambient operating temperature, humidity	0 to 40°C, 85% RH or less (Non-condensing)


(*) The value at lead 20 is shown in []. (**) Based on 5,000 km of traveling life.

Dimensional Drawings

CAD drawings can be downloaded from the website. www.intelligentactuator.com



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



* The dimensions in () apply when a brake is equipped.

Dimensions and Mass by Stroke

		Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L		Without brake	279	329	379	429	479	529	579	629	679	729	779	829	879	929	979	1029
		With brake	319	369	419	469	519	569	619	669	719	769	819	869	919	969	1019	1069
	A	73	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
	B	0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
	C	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7	
	D	4	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	
	F	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
	G	166	216	266	316	366	416	466	516	566	616	666	716	766	816	866	916	
	H	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
	J	0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
	K	181	231	281	331	381	431	481	531	581	631	681	731	781	831	881	931	
Mass	Without brake	1.5	1.6	1.8	1.9	2.1	2.2	2.4	2.5	2.6	2.8	2.9	3.1	3.2	3.4	3.5	3.7	
(kg)	With brake	1.7	1.9	2.0	2.1	2.3	2.4	2.6	2.7	2.9	3.0	3.2	3.3	3.5	3.6	3.7	3.9	

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.

Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-PLP-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points		Refer to the MSEP catalog.	Refer to the MSEP catalog.	Refer to the MSEP catalog.
Positioner multi-axis specification Network type		MSEP-C-□-~NP-□-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.


* In the model numbers shown above, □ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

Dimensional Drawings

CAD drawings can be downloaded from the website. www.intelligentactuator.com



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



* The dimensions in () apply when a brake is equipped.

Dimensions and Mass by Stroke

	Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	Without brake	299.5	349.5	399.5	449.5	499.5	549.5	599.5	649.5	699.5	749.5	799.5	849.5	899.5	949.5	999.5	1049.5
	With brake	339.5	389.5	439.5	489.5	539.5	589.5	639.5	689.5	739.5	789.5	839.5	889.5	939.5	989.5	1039.5	1089.5
A		0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800
B		0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7
C		1	1	2	2	3	3	4	4	5	5	6	6	7	8	8	8
D		4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20
E		2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3
F		4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18
G		186.5	236.5	286.5	336.5	386.5	436.5	486.5	536.5	586.5	636.5	686.5	736.5	786.5	836.5	886.5	936.5
H		0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
J		0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785
K		201.5	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5
Mass (kg)	Without brake	2.0	2.1	2.3	2.4	2.6	2.7	2.9	3.0	3.2	3.4	3.5	3.7	3.8	4.0	4.1	4.3
	With brake	2.2	2.3	2.5	2.6	2.8	3.0	3.1	3.3	3.4	3.6	3.7	3.9	4.1	4.2	4.4	4.5

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.


Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-42PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-42PI-PLN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-42PI-PLP-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□ MSEP-C-□-~PN-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.
Positioner multi-axis specification Network type		MSEP-C-□-~△-0-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points			Refer to the MSEP catalog.	Refer to the MSEP catalog.

* In the model numbers shown above, △ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

CAD drawings can be downloaded from the website.



- *1 Connect the motor and encoder cables.
- *2 During home return, be careful to avoid interference from peripheral objects because the slider travels until the mechanical end.



■ Dimensions and Mass by Stroke

		Stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	Without brake	352.5	102.5	452.5	502.5	552.5	602.5	652.5	702.5	752.5	802.5	852.5	902.5	952.5	1002.5	1052.5	1102.5	1152.5
	With brake	402.5	452.5	502.5	552.5	602.5	652.5	702.5	752.5	802.5	852.5	902.5	952.5	1002.5	1052.5	1102.5	1152.5	
A		0	100	100	200	200	300	300	400	400	500	500	600	600	700	700	800	
B		0	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	
C		1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	
D		4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	
E		2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
F		4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	
G		199	249	299	349	399	449	499	549	599	649	699	749	799	849	899	949	
H		0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
J		0	85	85	185	185	285	285	385	385	485	485	585	585	685	685	785	
K		219.5	269.5	319.5	369.5	419.5	469.5	519.5	569.5	619.5	669.5	719.5	769.5	819.5	869.5	919.5	969.5	
Mass (kg)	Without brake	3.4	3.6	3.8	4.1	4.3	4.6	4.8	5.1	5.3	5.6	5.8	6.0	6.3	6.5	6.8	7.0	
	With brake	3.9	4.1	4.3	4.6	4.8	5.1	5.3	5.6	5.8	6.1	6.3	6.5	6.8	7.0	7.3	7.5	

Applicable Controller

RCP4 series actuators can be operated with the controller indicated below. Select the type according to your intended application.


Name	External view	Model number	Features	Maximum number of positioning points	Input power	Power supply capacity	Standard price	Reference page
Positioner type		PCON-CA-56PI-NP-□-0-□	Equipped with a high-output driver Positioner type based on PIO control	512 points	DC24V	Refer to P. 48	—	Refer to P. 41
Pulse-train type		PCON-CA-56PI-PN-□-0-□	Equipped with a high-output driver Pulse-train input type	—			—	
Field network type		PCON-CA-56PI-PLN-□-0-□	Equipped with a high-output driver Supporting 7 major field networks	768 points			—	
Positioner multi-axis specification PIO type		MSEP-C-□-~NP-□-0-□	Positioner type based on PIO control, allowing up to 8 axes to be connected (high-output driver not supported)	3 points		Refer to the MSEP catalog.	Refer to the MSEP catalog.	Refer to the MSEP catalog.
Positioner multi-axis specification Network type		MSEP-C-□-~PN-□-0-□	Field network-ready positioner type, allowing up to 8 axes to be connected (high-output driver not supported)	256 points			Refer to the MSEP catalog.	

* In the model numbers shown above, □ indicates the field network specification (DV, CC, PR, CN, ML, EC or EP).

Notes on Installing Rod Actuators

When installing the actuator using the front housing or with a flange (optional), make sure the actuator will not receive external forces. (External forces may cause malfunction or damaged parts.) If the actuator will receive external forces or when the actuator is combined with a Cartesian robot, etc., use the mounting holes on the actuator base to secure the actuator.

Even when the actuator does not receive any external force, provide a support base to support the actuator, as shown in the figure on the right, if the actuator is installed horizontally and secured using a flange or through the bracket mounting holes of the side-mounted motor specification.




Selection Guideline (Correlation Diagram of Push Force and Current-limiting Value)

In push-motion operation, the push force can be used by changing the current-limiting value of the controller over a range of 20% to 70%. The maximum push-force varies depending on the model, so check the required push force from the table below and select an appropriate type meeting the purpose of use.


When performing push-motion operation using a slider actuator, limit the push current so that the reactive force moment generated by the push force will not exceed 80% of the rated moment (M_a , M_b) specified in the catalog. To help with the moment calculations, the application position of the guide moment is shown in the figure below. Calculate the necessary moment by considering the offset of the push force application position.

Note that if an excessive force exceeding the rated moment is applied, the guide may be damaged and the life may become shorter. Accordingly, include a sufficient safety factor when deciding on the push force.



Calculation example:

If push-motion operation is performed with a RCP4-SA7C by applying 100 N at the position shown to the right, the moment received by the guide, or M_a , is calculated as $(43 + 50) \times 100 = 9300$ (N·mm) = 9.3 (N·m).




Since the rated moment M_a of the SA7C is 13.9 (N·m), $13.9 \times 0.8 = 11.12 > 9.3$, suggesting that this selection is acceptable.

If a M_b moment generates due to push-motion operation, calculate the moment from the overhang and confirm, in the same way, that the calculated moment is within 80% of the rated moment.


The table below is only a reference, and the graphs may vary slightly from the actual values.

Correlation Diagrams of Push Force and Current-limiting value


SA5C/SA6C/RA5C type



SA7C type



RA6C type




Notes on Use

- The relationship of push force and current-limiting value is only a reference, and the graphs may vary slightly from the actual values.
- If the current-limiting value is less than 20%, the push force may vary. Make sure the current-limiting value remains 20% or more.
- The graphs assume a traveling speed of 20 mm/s during push-motion operation.

Selection References (Guide for Selecting Allowable Load for Radial Cylinder)


The radial cylinder has a built-in guide, so loads up to a certain level can be applied to the rod without using an external guide. Refer to the graphs below for the allowable load mass. If the allowable load will be exceeded under the required operating conditions, add an external guide.

■ Allowable load mass for RCP4-RA5□/6□, horizontally mounted



Allowable load calculation conditions
Load mass corresponding to a guide traveling life of 5,000 km, considering moments generated by acceleration/deceleration. (Acceleration: 1 G / Speed: 500 mm/s)

■ Allowable load mass for RCP4-RA5□/6□, vertically mounted



P con-CA

Positioner / Pulse-train Type
Controller with High-output Driver for RCP4
<Power CON 150>



1

Built-in high-output driver designed exclusively for RCP4 generates greater torque at high speed

The newly developed high-output driver (patent pending) achieves significantly improved specifications compared to conventional models (RCP2 series), with the acceleration/deceleration higher by 1.4 times, maximum speed by 1.5 times, and payload twice as large.

(*) The rates of improvement vary depending on the type.

Acceleration/ deceleration	RCP2	0.7G	
	RCP4	1.0G	1.4 times
Maximum speed	RCP2	1000mm/s	
	RCP4	1440mm/s	1.5 times
Payload	RCP2	6kg	
	RCP4	12kg	2 times

2

DeviceNet, CC-Link, PROFIBUS-DP, CompoNet, MECHATROLINK (I, II), EtherCAT, EtherNet/IP are supported

Features include wire-saving design, as well as the abilities to support direct numerical specification, position number specification, current position read, etc.




3

Incremental specification and simple absolute specification to choose from

You can choose one of the two types: the incremental specification and the simple absolute specification. The simple absolute specification is available in three types, including the specification having only the absolute battery attached on the side face of the actuator, specification equipped with the absolute battery unit where screw stopper/DIN rail mounting is possible, and controller-only specification without absolute battery.

(Note) All pulse-train Power CON controllers are of the incremental specification.




4

Smart tuning function, maintenance information, calendar function

The takt time minimization function sets an optimal acceleration/deceleration rate according to the load that is available (*). You can also record the number of times the actuator has moved and the distance that it has travelled, for use in maintenance.

(*) You need PC software Ver. 8.03.00.00 or later or a CON-PTA (teaching pendant) to use the takt time minimization function.




List of Models

ROBO Cylinder Position Controller PowerCON 150 <PCON-CA>

External view										
I/O type		Positioner type	Pulse-train type	Field network type						
				 DeviceNet	 CC-Link	 PROFIBUS-DP	 CompoNet	 MECHATROLINK	EtherCAT	 EtherNet/IP
				DeviceNet connection specification	CC-Link connection specification	PROFIBUS-DP connection specification	CompoNet connection specification	MECHATROLINK connection specification	EtherCAT connection specification	EtherNet/IP connection specification
I/O type model number		NP/PN	PLN/PLP	DV	CC	PR	CN	ML	EC	EP
Standard price	Incremental specification		-	-	-	-	-	-	-	-
	simple absolute specification	with absolute battery		-	-	-	-	-	-	-
		with absolute battery unit		-	-	-	-	-	-	-
		No absolute battery		-	-	-	-	-	-	-

Model Number





*The mounting specification for the absolute battery unit (screws mounting or DIN rail mounting) conforms to the mounting specification for the controller.

The PCON-CA controller can achieve high-speed, high-payload operations only when combined with RCP4 actuators. RCP2/RCP3 actuators also work with the PCON-CA controller, but only according to their original actuator specifications.

PIO I/O Interface



■ Input Part External Input Specifications

Item	Specification
Input voltage	24 VDC ± 10%
Input current	5mA, 1 circuit
ON/OFF voltage	ON voltage: 18 VDC min. OFF voltage: 6 VDC max.



■ Output Part External Output Specifications

Item	Specification
Load voltage	24 VDC
Maximum load current	50mA, 1 circuit
Leak current	2mA max. per point



Types of PIO Patterns (Control Patterns)

This controller supports seven types of control methods. Select in Parameter No. 25, "PIO pattern selection" the PIO pattern that best suits your purpose of use.

Type	Set value of Parameter No. 25	Mode	Overview
PIO pattern 0	0 (factory setting)	Positioning mode (standard type)	<ul style="list-style-type: none"> Number of positioning points: 64 points Position number command: Binary Coded Decimal (BCD) Zone signal output*: 1 point Position zone signal output*: 1 point
PIO pattern 1	1	Teaching mode (teaching type)	<ul style="list-style-type: none"> Number of positioning points: 64 points Position number command: Binary Coded Decimal (BCD) Position zone signal output*: 1 point • Jog (inching) operation using PIO signals is supported. Current position data can be written to the position table using PIO signals.
PIO pattern 2	2	256-point mode (256 positioning points)	<ul style="list-style-type: none"> Number of positioning points: 256 points Position number command: Binary Coded Decimal (BCD) Position zone signal output*: 1 point
PIO pattern 3	3	512-point mode (512 positioning points)	<ul style="list-style-type: none"> Number of positioning points: 512 points Position number command: Binary Coded Decimal (BCD) No zone signal output
PIO pattern 4	4	Solenoid valve mode 1 (7-point type)	<ul style="list-style-type: none"> Number of positioning points: 7 points Position number command: Individual number signal ON Zone signal output*: 1 point Position zone signal output*: 1 point
PIO pattern 5	5	Solenoid valve mode 2 (3-point type)	<ul style="list-style-type: none"> Number of positioning points: 3 points Position number command: Individual number signal ON Completion signal: A signal equivalent to a LS (limit switch) signal can be output. Zone signal output*: 1 point Position zone signal output*: 1 point
PIO pattern 6 (Note)	6	Pulse-train control mode	<ul style="list-style-type: none"> Differential pulse input (200 kpps max.) Home return function Zone signal output*: 2 points No feedback pulse output

*1 Zone signal output: A desired zone is set by Parameter Nos. 1 and 2 or 23 and 24, and the set zone always remains effective once home return has completed.

*2 Position zone signal output: This function is available as part of a position number. A desired zone is set in the position table and becomes effective only when the corresponding position is specified, but not with commands specifying other positions.

(Note) Pulse Train Control Model is available only if the pulse train control type is indicated (from PCON-CA-*PLN and PLP) at the time of purchase.

PIO Patterns and Signal Assignments

The table below lists the signal assignments for the I/O flat cable under different PIO patterns. Connect an external device (such as a PLC) according to this table.

Pin number	Category	PIO function	Parameter No. 25, "PIO pattern selection"					
			0	1	2	3	4	5
			Positioning mode	Teaching mode	256-point mode	512-point mode	Solenoid valve mode 1	Solenoid valve mode 2
Input	Input	Number of positioning points	64 points	64 points	256 points	512 points	7 points	3 points
		Home return signal	○	○	○	○	○	×
		Jog signal	×	○	×	×	×	×
		Teaching signal (writing of current position)	×	○	×	×	×	×
	Output	Brake release	○	×	○	○	○	○
		Moving signal	○	○	×	×	×	×
		Zone signal	○	△ (Note 1)	△ (Note 1)	×	○	○
		Position zone signal	○	○	○	×	○	○
1A	24V				P24			
2A	24V				P24			
3A	Pulse input				—			
4A					—			
5A	Input	IN0	PC1	PC1	PC1	PC1	ST0	ST0
6A		IN1	PC2	PC2	PC2	PC2	ST1	ST1(JOG+)
7A		IN2	PC4	PC4	PC4	PC4	ST2	ST2(-)
8A		IN3	PC8	PC8	PC8	PC8	ST3	—
9A		IN4	PC16	PC16	PC16	PC16	ST4	—
10A		IN5	PC32	PC32	PC32	PC32	ST5	—
11A		IN6	—	MODE	PC64	PC64	ST6	—
12A		IN7	—	JISL	PC128	PC128	—	—
13A		IN8	—	JOG+	—	PC256	—	—
14A		IN9	BKRL	JOG-	BKRL	BKRL	BKRL	BKRL
15A		IN10	RMOD	RMOD	RMOD	RMOD	RMOD	RMOD
16A		IN11	HOME	HOME	HOME	HOME	HOME	—
17A		IN12	*STP	*STP	*STP	*STP	*STP	—
18A		IN13	CSTR	CSTR/PWRT	CSTR	CSTR	—	—
19A		IN14	RES	RES	RES	RES	RES	RES
20A		IN15	SON	SON	SON	SON	SON	SON
1B	Output	OUT0	PM1(ALM1)	PM1(ALM1)	PM1(ALM1)	PM1(ALM1)	PE0	LSO
2B		OUT1	PM2(ALM2)	PM2(ALM2)	PM2(ALM2)	PM2(ALM2)	PE1	LS1(TRQS)
3B		OUT2	PM4(ALM4)	PM4(ALM4)	PM4(ALM4)	PM4(ALM4)	PE2	LS2 (Note 2)
4B		OUT3	PM8(ALM8)	PM8(ALM8)	PM8(ALM8)	PM8(ALM8)	PE3	—
5B		OUT4	PM16	PM16	PM16	PM16	PE4	—
6B		OUT5	PM32	PM32	PM32	PM32	PE5	—
7B		OUT6	MOVE	MOVE	PM64	PM64	PE6	—
8B		OUT7	ZONE1	MODES	PM128	PM128	ZONE1	ZONE1
9B		OUT8	PZONE/ZONE2	PZONE/ZONE1	PZONE/ZONE1	PM256	PZONE/ZONE2	PZONE/ZONE2
10B		OUT9	RMDS	RMDS	RMDS	RMDS	RMDS	RMDS
11B		OUT10	HEND	HEND	HEND	HEND	HEND	HEND
12B		OUT11	PEND	PEND/WEND	PEND	PEND	PEND	—
13B		OUT12	SV	SV	SV	SV	SV	SV
14B		OUT13	*EMGS	*EMGS	*EMGS	*EMGS	*EMGS	*EMGS
15B		OUT14	*ALM	*ALM	*ALM	*ALM	*ALM	*ALM
16B		OUT15	LOAD/TRQS *ALML	*ALML	LOAD/TRQS *ALML	LOAD/TRQS *ALML	LOAD/TRQS *ALML	*ALML
17B	Pulse input				—			
18B					—			
19B	0V				N			
20B	0V				N			

(Note) In the table above, asterisk * symbol accompanying each code indicates a negative logic signal. PM1 to PM8 are alarm binary code output signals that are used when an alarm generates.

(Note 1) In all PIO patterns other than 3, this signal can be switched with PZONE by setting Parameter No. 149 accordingly.

(Note 2) The setting will not become effective until the origin return is completed.


Reference) Negative logic signal

Signals denoted by * are negative logic signals. Negative logic input signals are processed when turned OFF. Negative logic output signals normally remain ON while the power is supplied, and turn OFF when the signal is output.

Note: The names of the signals above inside () are functions before the unit returns home.


Pulse-train Control Circuit

■ Host Unit = Differential Type









■ Host Unit = Open Collector Type

The AK-04 (optional) is needed to input pulses.



Caution: Use the same power supply for open collector input/output to/from the host and for the AK-04.

Command Pulse Input Patterns

	Command pulse-train pattern	Input terminal	Forward	Reverse
Negative logic	Forward pulse-train	PP./PP		
	Reverse pulse-train	NP./NP		
	A forward pulse-train indicates the amount of motor rotation in the forward direction, while a reverse pulse-train indicates the amount of motor rotation in the reverse direction.			
	Pulse-train	PP./PP		
	Sign	NP./NP	Low	High
	The command pulses indicate the amount of motor rotation, while the sign indicates the rotating direction.			
Positive logic	Phase A/B pulse-train	PP./PP		
		NP./NP		
	Command phases A and B having a 90° phase difference (multiplier is 4) indicate the amount of rotation and the rotating direction.			
	Forward pulse train	PP./PP		
	Reverse pulse-train	NP./NP		
	Pulse-train	PP./PP		
Positive logic	Sign	NP./NP	High	Low
	Phase A/B pulse-train	PP./PP		
		NP./NP		

I/O Signals in Pulse-train Control Mode

The table below lists the signal assignments for the flat cable in the pulse-train control mode.
Connect an external device (such as PLC) according to this table.

Pin number	Category	I/O number	Signal abbreviation	Signal name	Parameter No. 25, "PIO pattern 6"
1A	24V		P24	Power supply	I/O power supply +24 V
2A	24V		P24	Power supply	I/O power supply +24 V
3A	Pulse input		PP	Differential pulse-train input (+)	Differential pulses are input from the host. Up to 200 kpps can be input.
4A			/PP	Differential pulse-train input (-)	
5A		IN0	SON	Servo ON	The servo is ON while this signal is ON, and OFF while the signal is OFF.
6A		IN1	RES	Reset	Present alarms are reset when this signal is turned ON.
7A		IN2	HOME	Home return	Home return operation is performed when this signal is turned ON.
8A		IN3	TL	Torque limit selection	When this signal is turned ON, the motor torque is limited to the value set by the parameter.
9A		IN4	CSTP	Forced stop	The actuator is forcibly stopped when this signal has remained ON for 16 ms or more. The actuator decelerates to a stop at the torque set in the controller and the servo turns OFF.
10A		IN5	DCLR	Deviation counter clear	This signal clears the deviation counter.
11A		IN6	BKRL	Forced brake release	The brake is forcibly released.
12A		IN7	RMOD	Operation mode switching	The operation mode can be switched when the MODE switch on the controller is set to AUTO. (AUTO when this signal is OFF, and to MANU when the signal is ON.)
13A		IN8	NC	—	Not used
14A		IN9	NC	—	Not used
15A		IN10	NC	—	Not used
16A		IN11	NC	—	Not used
17A		IN12	NC	—	Not used
18A		IN13	NC	—	Not used
19A		IN14	NC	—	Not used
20A		IN15	NC	—	Not used
1B	Output	OUT0	PWR	System ready	This signal turns ON when the controller becomes ready after the main power has been turned on.
2B		OUT1	SV	Servo ON status	This signal turns ON when the servo is ON.
3B		OUT2	INP	Positioning complete	This signal turns ON when the amount of remaining travel pulses in the deviation counter falls within the in-position band.
4B		OUT3	HEND	Home return complete	This signal turns ON upon completion of home return.
5B		OUT4	TLR	Torque limited	This signal turns ON upon reaching the torque limit while the torque is limited.
6B		OUT5	*ALM	Controller alarm status	This signal turns ON when the controller is normal, and turns OFF when an alarm generates.
7B		OUT6	*EMGS	Emergency stop status	This signal turns ON when the emergency stop of the controller is cancelled, and turns OFF when an emergency stop is actuated.
8B		OUT7	RMDS	Operation mode status	The operation mode status is output. This signal turns ON when the controller is in the manual mode.
9B		OUT8	ALM1	Alarm code output signal	An alarm code is output when an alarm generates. For details, refer to the operation manual.
10B		OUT9	ALM2		
11B		OUT10	ALM4		
12B		OUT11	ALM8		
13B		OUT12	*ALML	Minor failure alarm	This signal is output when a message-level alarm generates.
14B		OUT13	NC	—	Not used
15B		OUT14	ZONE1	Zone signal 1	This signal turns ON when the current position of the actuator falls within the parameter-set range.
16B		OUT15	ZONE2	Zone signal 2	
17B	Pulse input		NP	Differential pulse-train input (+)	Differential pulses are input from the host. Up to 200 kpps can be input.
18B			/NP	Differential pulse-train input (-)	
19B	0V		N	Power supply	I/O power supply 0 V
20B	0V		N	Power supply	I/O power supply 0 V

(Note) * indicates a negative logic signal. Negative logic signals are normally ON while the power is supplied, and turn OFF when the signal is output.

(Note) The number of encoder pulses is 800 with all RCP4 series models. For details, refer to the operation manual.

Field Network Specification: Explanation of Operation Modes

If the PCON-CA is controlled via a field network, you can select one of the following five modes to operate the actuator. Take note that the required data areas on the PLC side vary depending on the mode.

■ Explanation of Modes

	Mode	Description
0	Remote I/O mode	In this mode, the actuator is operated by controlling the ON/OFF of bits via the network, just like with the PIO specification. The number of positioning points and functions vary with each of the operation patterns (PIO patterns) that can be set by the controller's parameter.
1	Position/simple direct numerical mode	The target position is specified by directly entering a value, while other operating conditions (speed, acceleration, etc.) are set by specifying the desired position number corresponding to the desired operating conditions already input to the position data table.
2	Half direct numerical mode	The actuator is operated by specifying the speed, acceleration/deceleration and push current, in addition to the target position, by directly entering values.
3	Full direct numerical mode	The actuator is operated by specifying the target position, speed, acceleration/deceleration, push current control value, etc., by directly entering values. The current position, current speed, command current, etc., can also be read.
4	Remote I/O mode 2	Same as the above remote I/O mode, plus the current position read function and command current read function.

■ Required Data Size for Each Network

		DviceNet	CC-Link	PROFIBUS-DP	CompoNet	MECHATROLINK I, II	EtherCAT	EtherNet/IP
0	Remote I/O mode	1CH	1 station	2 bytes	2 bytes	*	2 bytes	2 bytes
1	Position/simple direct numerical mode	4CH	1 station	8 bytes	8 bytes	*	8 bytes	8 bytes
2	Half direct numerical mode	8CH	2 stations	16 bytes	16 bytes	*	16 bytes	16 bytes
3	Full direct numerical mode	16CH	4 stations	32 bytes	32 bytes	*	32 bytes	32 bytes
4	Remote I/O mode 2	6CH	1 station	12 bytes	12 bytes	*	12 bytes	12 bytes

* No required data size is set for MECHATROLINK I and II.


■ List of Functions by Operation Mode

	Remote I/O mode	Position/simple direct numerical mode	Half direct numerical mode	Full direct numerical mode	Remote I/O mode 2
Number of positioning points	512 points	768 points	Not limited	Not limited	512 points
Operation by direct position data specification	X	O	O	O	X
Direct speed/acceleration specification	X	X	O	O	X
Push-motion operation	O	O	O	O	O
Current position read	X	O	O	O	O
Current speed read	X	X	O	O	X
Operation by position number specification	O	O	X	X	O
Completed position number read	O	O	X	X	O

* O indicates that the operation is supported, and X indicates that it is not supported.

(Note 1) Take note that the MECHATROLINK specification does not support the full direct numerical mode.

External Dimensions



Specification Table

Item		Description	
Number of controlled axes		1 axis	
Power supply voltage		24VDC ± 10%	
Load capacity (Current consumption of controlled axes included) (Note 1)	RCP2	Motor type	20P, 28P, 20SP, 28SP 35P, 42P, 56P 60P, 86P
	RCP3	Motor type	1A max. 2.2A max.
	RCP4	Motor type	High-output setting disabled: 2.0A max. High-output setting enabled: 3.5A rated / 4.2 max.
Power supply for electromagnetic brake (for actuators with brake)		24VDC ± 10%, 0.15A (max.)	
Rush current (Note 1)		8.3A	
Momentary power failure resistance		500μs max.	
Applicable encoder		Incremental encoder of 800 pulses/rev in resolution	
Actuator cable length		20m max.	
External interface	PIO specification	Dedicated 24-VDC signal input/output (NPN or PNP selected) --- Up to 16 input points, up to 16 output points / Cable length: 10m max.	
	Field network specification	DeviceNet, CC-Link, PROFIBUS, CompoNET, MECHATROLINK, EtherCAT, EtherNet/IP	
Data setting/input method		PC software, touch-panel teaching pendant	
Data retention memory		Position data and parameters are saved in the non-volatile memory (The memory can be written an unlimited number of times.)	
Operation modes		Positioner mode / Pulse-train control mode (Selectable by parameter setting)	
Number of positions in positioner mode		Up to 512 points for the positioner type, up to 768 points for the network type (Note) The number of positioning points varies depending on the PIO pattern selected.	
Pulse-train interface	Input pulse	Differential method (line driver method): 200kpps max. / Cable length: 10m max.	
		Open collector method: Not supported * If the host uses open-collector output, convert the open-collector pulses to differential pulses using the AK-04 (available as an option).	
	Command pulse magnification (electronic gear ratio: A/B)	1/50 < A/B < 50/1 Setting range of A and B (set by parameters): 1 to 4096	
Feedback pulse output		None	
Isolation resistance		500-VDC 10 MΩ or more	
Electric shock protection mechanism		Class I basic isolation	
Mass (Note 3)	Incremental specification	Screw fastening type: 250g or less	DIN rail securing type: 285g or less
	Simple absolute specification (190g of battery weight included)	Screw fastening type: 450g or less	DIN rail securing type: 485g or less
Cooling method		Natural air cooling	
Environment	Ambient operating temperature	0 to 40°C	
	Ambient operating humidity	85%RH or less (non-condensing)	
	Operating ambience	Not exposed to corrosive gases	
	Protection degree	IP20	

(Note 1) The value increases by 0.3 A for the field network specification.

(Note 2) After the power is turned on, rush current will flow for approx. 5msec (at 40°C). Take note that the rush current varies depending on the impedance of the power-supply line.

(Note 3) The value increases by 30g for the field network specification.


Option

Teaching pendant

■ Summary Teaching device for positioning input, test operation, and monitoring.

■ Model **CON-PTA-C** (Touch panel teaching pendant)

■ Setting



Specification

Item	CON-PTA-C
Data input	○
Actuator motion	○
Operating ambient temperature/humidity	Temperature 0 to 40°C, humidity 85% RH or less
Operating environment	Free from corrosive gas and especially, considerably dusty condition
Protection degree	IP40
Weight	Approximately 570g
Cable length	5m
Display	65536 color White LED back light
Standard price	—

PC software (Windows only)


* For the MSEP field network specification, the PC software is required.

■ Summary A startup support software for inputting positions, performing test runs, and monitoring. With enhancements for adjustment functions, the startup time is shortened.

■ Model **RCM-101-MW** (External device communication cable + RS232 conversion unit)

■ Setting


MSEP is supported by Ver.9.01.00.00 or later



■ Model **RCM-101-USB** (External device communication cable + USB converter adaptor + USB cable)

■ Setting

MSEP is supported by Ver.9.01.00.00 or later



Absolute Battery Unit


■ Summary Battery unit that comes with a simple absolute controller, used to back up the current controller position.

■ Model **SEP-ABU** (DIN rail mount specification)

SEP-ABUS (screw fixing specification)

■ Specifications

Item	Specification
Ambient operating temperature, humidity	0 to 40°C (desirably around 20°C), 95% RH or below (non-condensing)
Operating ambience	Free from corrosive gases
Absolute battery	Model number: AB-7 (Ni-MH battery / Life: Approx. 3 years)
Controller/absolute battery unit link cable	Model number: CB-APSEP-AB005 (Length: 0.5m)
Mass	Standard type: Approx. 230g / Dust-proof type: Approx. 260g



Replacement battery

■ Summary The replacement battery for the absolute data backup battery box.

■ Model **AB-7**



IAI America, Inc.

Headquarters: 2690 W. 237th Street, Torrance, CA 90505 (800) 736-1712

Chicago Office: 1261 Hamilton Parkway, Itasca, IL 60143 (800) 944-0333

Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066 (888) 354-9470

The information contained in this product brochure may change without prior notice due to product improvements.

IAI Industrieroboter GmbH

Ober der Roth 4, D-65824 Schwalbach am Taunus, Germany

www.intelligentactuator.com

